



# Resetting the Paragon2

- \* Place the engine on an unpowered track.
- \* Press down, and hold the momentary push button on the reset switch.
- \* Turn on the track power.
- \* You will hear an acknowledgment the Reset took place.
- \* Release the reset button.



*Hardware Reset Button*

