



Resetting the Paragon2

- * Place the engine on an unpowered track.
- * Press down, and hold the momentary push button on the reset switch.
- * Turn on the track power.
- * You will hear an acknowledgment the Reset took place.
- * Release the reset button.



Hardware Reset Button

