



Steam Locomotive Operation Manual

for QSI Quantum 1 System™ Analog & DCC Sound
Decoder Equipped Locomotives with Potentiometer



13 April 2006
Version 3.1

Basic Analog Operation

QSI recommends that you get used to operating and having fun with your new sound-equipped locomotive before exploring its more advanced features or programming options. Read through this section and be up and running with your new Quantum equipped locomotive in less than five minutes.

Running the Locomotive

Use an HO power pack with a standard direction switch¹. Set the switch to run your locomotive Forward.

- Turn the throttle up slowly until you hear the Quantum System™ come on. You will hear Start Up sounds and the dynamo will rev up as the headlight comes on.
- Continue to turn up the throttle voltage until the locomotive starts to move in Forward. The directional headlight will come on bright and the optional Mars light will start pulsing. The locomotive will start out slowly due to special Quantum Inertial Control that resists rapid increases or decreases in speed².
- As you slow the locomotive down by gradually reducing the throttle, Squealing Brake sounds occur as it comes to a stop.

Reversing the Locomotive

This simple operation is exactly the same as with standard locomotives.

- Bring the locomotive to a stop and turn the power all the way off.
- Flip the direction switch and reapply power to go in the opposite direction.

The optional steam tender reverse light comes on in reverse. If so equipped, the Mars Light will stop pulsing and switch to dim. The front headlight will switch to off or switch to dim if the dim headlight feature is available.

Whistle

Blow the authentic Steam Locomotive Whistle for short or long blasts – you control the duration.

- While the locomotive is **moving**, flip the direction switch to turn on the Whistle.
- Flip the direction switch back to shut off the Whistle.

The locomotive will not change direction when you blow the Whistle.

Note: If you flip the direction switch too slowly from one position to the other, you can momentarily lose track power as the switch is being moved through its center position.

Bell (available on all U.S. and other selected models)³

You can turn the Bell on (if so equipped) and leave it on while you operate other functions on the locomotive.

- Turn the Bell **on** with a **Quick** flip-and-back operation of the direction switch.
- Turn the Bell **off** with a second **Quick** flip-and-back operation of the direction switch.

The Bell will stay on until you do another **Quick** flip-and-back operation of the direction switch to turn it off, or if you interrupt the track power. If you do a **Slow** flip-and-back operation, you will get a short Whistle hoot instead of the Bell. If you try to do a very short Whistle blast using a **Quick** operation, you will activate the Bell instead. If you have trouble doing the **Quick** flip-and-back operation, try holding the power pack in place with your other hand to keep the unit from slipping.

Note: When you toggle the Bell off, it will continue ringing briefly with less volume as the pneumatic clapper or swinging bell slows down, just like the prototype.

1 If your power pack has a reversing-throttle that changes from forward to off to reverse in a continuous manner, we recommend that you install a reversing slide-switch between power pack and track. Suitable double-pole double-throw reversing switches are available at most model railroad hobby shops or electronic supply stores.

2 See Locomotive *Inertia Effects* on page 3 for further description of this feature. Re-programming your locomotive to use Standard Throttle Control (STC) will disable the inertial effects that occur with Regulated Throttle Control (RTC). See Example 1, pages 8-9.

3 If the prototype locomotive does not have a bell, your model will not have the Bell feature. However, all Quantum locomotives have a "Bell State" used for a number of Quantum operations. The Bell State is turned on and off with a Quick Flip and Back operation of the reverse switch as described. You will hear a single bell ding when you enter the Bell State and a double ding when you leave the Bell State.

Advanced Analog Features

Starting the Locomotive

Most HO DC power packs with a standard reversing switch⁴ are suitable for Analog operation. Generally, modern electronic type power packs will provide better performance.

When operated with a standard DC power pack, your Quantum equipped steam locomotive behaves quite differently from other locomotives you may have operated. Unlike standard HO locomotives that start at very low track voltages, Quantum equipped locomotives require a minimum amount of voltage to operate the electronics. Also, the response to the throttle is realistically much slower, just like a prototype locomotive.

- Turn the throttle up slowly until you hear the Quantum System™ come on with a Long Air Let-off sound, Air Pumps, Blower hiss and the Dynamo revving as the Headlight comes up to its “dim” setting. Optional Number Board Lights and Firebox Lights will turn on and Cab Lights⁵ will turn on after 10 seconds. If your locomotive has a Mars light, it will be dim and the front headlight will be off. See a table summary of Directional Lighting operation in the DCC section of this manual.
- Continue⁶ to turn up the throttle voltage until the locomotive starts to move in Forward (this voltage is called V-Start⁷). Steam exhaust (chuffing) will sound in sync with the motion of the drive wheels and in proportion to the locomotive’s Intrinsic Inertia and Load setting (see QSI Sound of Power® on page 5) and the locomotive will slowly start to move. The Headlight will switch to bright and the optional Mars light will begin to pulse. After 10 seconds in Forward, the Cab Lights (if so equipped) will automatically shut off.

Locomotive Inertia Effects

Your new locomotive is pre-programmed at the factory to use Regulated Throttle Control (RTC) in Analog (DC powered) operation. RTC makes your locomotive operate as though it has the mass and inertia of a prototype locomotive. As a result, your locomotive will resist starting up too quickly if at rest and will resist changes in speed once moving (see *Standard Throttle Control™ (STC™) and Regulated Throttle Control™ (RTC™)* on page 4). It takes a little practice to learn to move the throttle slowly and wait until the locomotive responds. If you prefer that your locomotive respond almost immediately to throttle movements on your DC power pack, it may be reprogrammed to use Standard Throttle Control (STC). Under STC there is no Inertial Control. The Example at the bottom of page 8 in the Owners Manual explains how to program your locomotive to use STC.

- As you slow the locomotive down by gradually reducing the throttle to a little below V-start, the steam chuff labored sound volume decreases, while Squealing Brake sounds occur as the steam locomotive comes to a slow stop⁸.

Note: If your locomotive has two sets of drivers, you will hear two sets of steam chuff sounds that will go gradually in and out of synchrony.

Note: If you need to turn your throttle up quite high to start your Steam Locomotive, V-Start can be adjusted for operation with your particular DC power pack (see Analog Programming on pages 7-9). For recommended power packs, consult the *Quantum Analog Reference Manual* (Version 3) available at <http://www.qsindustries.com>.

Doppler Effect

This sound effect changes the pitch and volume of the Whistle, Bell and other steam locomotive sounds as the locomotive passes.

- While the locomotive is moving toward the observer, flip the direction switch to turn on the Whistle.
- Wait at least one second while the Whistle is blowing.
- Just before the locomotive passes in front of the observer, flip the direction switch back and forth quickly so the Whistle does not shut off. You will hear the Doppler Effect as the locomotive passes by.
- Either flip the direction switch back to shut off the Whistle, or continue with long or short Whistle operations. When you are finished blowing the whistle, the locomotive sounds will automatically return to normal after a few seconds. If the Bell was on, it will shut off just before the sounds return to normal.

Note: The faster the locomotive is moving, the greater the Doppler shift. Below 15 smph, there is no Doppler shift.

4 Some electronic power packs do not have a reverse switch. Instead they have a reverse button, which does not cause a rapid change in track polarity to the track and is not suitable for Quantum operation. See the list of suitable power packs in the *Quantum Analog Reference Manual* (Version 3) at <http://www.qsindustries.com>.

5 Your steam locomotive may not have all lights described here, depending on the model.

6 It is not necessary to wait for the locomotive Start Up to finish before entering Forward. If you turn up the throttle, the Start Up sounds terminate and the steam locomotive will immediately go into normal Forward operation.

7 V-Start is set by default at 8.5 volts. It is important to note where V-Start is located on your conventional DC throttle control knob to know where you will enter and leave Neutral (see Neutral on Page 4).

8 Squealing Brakes occur if the locomotive exceeds 40 scale-miles per hour (smph) (64.4 scale kilometers/hour) and then slows down to below 20 smph (32 skph).

Special Whistle Ending Sound

Prototype engineers would often “play” their whistles by controlling the flow of steam to the whistle chamber. In particular, engineers often had a signature sound associated with how they ended their whistle sequences. Some Quantum sound sets have special Whistle Endings that can be activated using the direction switch to produce a unique sound effect similar to that of a prototype engineer’s “playing” the whistle.

- Flip the direction switch to blow the Whistle for at least one second.
- The normal way to end the Whistle is to flip the direction switch back. To do the special Whistle Ending, add an immediate **Quick** flip-and- back operation.

Note: If you wait too long to do the Quick Flip-and-Back operation, the Bell might turn on instead.

Note: Your Quantum equipped locomotive may not have special Whistle Ending sounds included.

Neutral

In Neutral, the locomotive will continue to make prototypical sounds appropriate to its resting state.

- Enter Neutral by **turning the throttle down below V-Start but not off and wait for locomotive to stop**⁹. The Headlight or (if so equipped) the Mars light switches to a steady dim and Reverse Light will turn off if entering Neutral From Reverse (NFR).
- You will hear a Short Air Let-off when the locomotive stops moving and enters Neutral, and a Long Air Let-off about three seconds later followed by Air Pumps and other background sounds such as steam boiler Pop-Off, boiler Blow Down, and Water Injector sounds.
- After the Air Pumps start, you can also use the direction switch to blow the Whistle or turn on or off the Bell (if so equipped)¹⁰.

If you cannot enter Neutral, or have difficulties with any of the operations, you may need to program your locomotive for optimal use with your particular DC power pack (see Analog Programming in next section).

Changing the Locomotive’s Direction without Turning off the Sound

You can use the power pack’s direction switch while the locomotive is in Neutral to change the locomotive’s direction.

- Put the locomotive in Neutral by bringing the throttle down below V-start and wait for the locomotive to stop¹¹.
- Flip the direction switch after you hear the Short Air Let-off but before you hear the Long Air Let-off and the Air Pump sounds turn on. During this short time (3 seconds) the Whistle will not blow when you flip the direction switch.
- Turn up the throttle anytime thereafter to operate the locomotive in the opposite direction.

If you have waited until the Air Pumps start in Neutral and now wish to change direction, you can either:

1. Turn the power all the way off, change the direction switch and turn the power back on, or,
2. Flip the direction switch (the Whistle will come on) and then turn up the throttle. When the locomotive starts to move in the opposite direction, the Whistle will stop automatically and then hoot one more time if the direction is Forward for a total of two hoots. Or if the direction is Reverse, the Whistle will hoot two more times for a total of three hoots¹².

Note: To prevent the first Whistle hoot from being too long, do not delay in turning up the throttle after you have flipped the direction switch.

Standard Throttle Control™ (STC™) and Regulated Throttle Control™ (RTC™)

Quantum locomotives have two types of Analog throttle control available, Standard and Regulated. Both Standard Throttle Control (STC) and Regulated Throttle Control (RTC) will apply more power to the motor as a function of increasing track voltage beginning at the V-Start setting. RTC includes an Inertial Control feature that prevents the locomotive from reacting quickly to changes in voltage or minor impediments to motion such as misaligned track joints, tight curves, rough turn-outs, etc. A locomotive under STC may come to an unrealistic halt from a raised track joint or a drop in voltage¹³ while the same locomotive under RTC, with its Inertial Control, will continue at the same speed. RTC operates your locomotive as though it has the mass and inertia of a prototype locomotive; your locomotive will resist changes in speed once it is moving and will resist starting up quickly if at rest. You will be able to operate your locomotive at very slow prototypical speeds without having to adjust your throttle voltage continually to maintain speed.

9 If Regulated Throttle Control is enabled (see below) it is important to wait until the locomotive stops on its own. The locomotive’s electronic Inertial Control will keep it moving even though you have reduced the throttle far enough below V-Start to stop the locomotive. In your attempt to stop the locomotive, do not try to reduce the throttle so far that all sounds turn off.

10 In Neutral, a mechanical Bell feature may have a distinctive turn-on effect as the pneumatic clapper gains full motion to strike the bell. The Bell may also have a shut-down effect where each strike becomes less loud as the clapper slows its motion. On pull bells, ringing will continue to sound as the bell slows to a stop.

11 On some power packs that have high internal resistance, the track voltage may rise slightly as the locomotive slows down and requires less power to operate. With these power packs, as the locomotive slows, you may need to reduce the throttle a little more to remain below V-Start.

12 Standard U.S. prototype railroad signaling is two hoots before starting in forward and three hoots before starting in reverse. Other countries have different signaling. Check your Steam Model Specification sheet for whistle sequences used on your model.

13 For instance, blowing the Whistle takes power and can reduce track voltage substantially and quickly. Under STC at low speeds, blowing the Whistle can stop your locomotive. Under RTC blowing the Whistle will not cause your locomotive to stop or slow abruptly.

While small obstacles will not affect the locomotives speed under RTC, a continual force will slow your train down, just like the prototype. For instance, if your steam locomotive encounters an upward grade under RTC, it will eventually slow down. Providing more throttle will slowly accelerate it back to speed. The same locomotive under STC would quickly slow down or stop if it encountered an upward grade.

The type of throttle control also affects how your locomotive decelerates. Under STC, your locomotive will respond quickly to a reduction in track voltage. Under RTC, your locomotive will decelerate slowly as you bring the throttle down. If you bring the throttle down below V-Start, the locomotive will slowly come to a stop. You can however, force a locomotive to slow down rapidly under RTC by bringing the throttle down quickly; this action reduces the power available to the motor inertial control circuit and forces the speed to decrease faster than RTC would normally allow. Once the locomotive slows down and regains normal RTC operation, it will continue to decelerate slowly according to its built-in Inertia and Load setting. For instance, if your locomotive was running at top speed and you quickly reduced the track voltage to just below V-Start (where the locomotive would normally be stopped) the locomotive would at first slow down rapidly as you reduced the available power to the motor. After this initial rapid slow down, the locomotive would decelerate at a rate determined by the RTC Inertial Control and Load setting and finally coast to a stop.

STC and RTC are selected under Analog Programming (see next section). The default is RTC.

Train Load

You can set your steam locomotive to have any of 16 different Load levels, which represent added inertia from rolling stock (see Analog Programming, Option 2, in next section). The higher the Load setting, the greater the inertia effect during acceleration and deceleration. As you increase track voltage, the motor is provided an increasing portion of that voltage which, depending on the Load setting, will gradually accelerate the locomotive realistically until it reaches full speed. Level 0 is the default, which is no Load.

Under STC, the level 0 Load setting will allow your locomotive to accelerate or stop as quickly as the internal flywheels will allow. Under RTC, level 0 will add no additional Load to the Intrinsic Inertia already provided by RTC. For any Load setting from 1-15, your steam locomotive will take longer to change speed under either STC or RTC. At level 1, it will take approximately 15 seconds more to achieve full speed at max throttle¹⁴; at level 15, it will take over 3 ½ minutes to achieve full speed. In addition, at higher Load settings, your locomotive will decelerate more slowly as you decrease your throttle.

Sound of Power™

Your steam locomotive will produce Sound-of-Power labored steam sound effects under RTC or under STC as long as you have selected any of the Load settings from level 1 to 15. Under acceleration, the Chuffing sounds will be more labored until the locomotive has achieved its final speed where it will then produce standard sounds appropriate to its throttle setting. Under deceleration, the locomotive Chuffing sounds are less labored until it achieves its final speed where it will again produce standard steam sounds appropriate to its throttle setting.

Helpers

Prototype Helpers are locomotives that are used to provide extra power and/or braking for a heavily loaded train. These helper locomotives can be part of the head-end consist or as mid-train helpers or as pushers at the end of the train. Helper locomotives behave differently than the train's lead locomotive. Their whistles and bells are usually not operated and their lighting options are different or not used at all.

When you make up your train using more than one locomotive, the Quantum System allows you to easily program how each locomotive will behave by selecting between a Lead locomotive, Mid Helper, End Helper, or Pusher. Each type of Helper locomotive has different lighting and sound characteristics as described in the table in the next section on Analog Programming, Option 3, on page 7.

Normal and Reversed Direction

Quantum also allows you to reverse the directional sense of your locomotive. This capacity is normally not an issue with DC two-rail trains since all locomotives will go in the same direction whether they are facing forwards or backwards. However, certain features like Directional Lighting do depend on the directional sense. For instance, if you program your locomotive to be an End Helper for your consist, its tender Reverse Light operates when the locomotive is moving in Reverse and the front Headlight is disabled. This arrangement is ideal for providing a Reverse Light for the consist. However, if this steam locomotive is facing backwards at the end of a consist, the Reverse Light faces forward and will be lit when the consist is moving Forward and there will be no Reverse Light for the consist. The "Direction" program feature will ensure that this End Helper's backward facing Headlight will come on only when the consist is backing up and the forward facing Reverse Light will not light at all. When making up a train with different Helper types, it is recommended that you also change the directional sense of any Helper that is intended to be operated backwards within the consist. See "Option 4 Direction", Analog Programming, next section.

¹⁴ Some unloaded power packs produce excessive voltage at max throttle and will activate the Quantum high voltage circuit breaker. When this happens, your locomotive will stop and emit a series of hoots until the power is reduced to a lower voltage (see Troubleshooting, page 20).

Additional Analog Operation Features Available with the Quantum Engineer™ Controller

Your Quantum steam locomotive is equipped with our new QSI's QARC™ (Quantum Analog Remote Control) Technology, which uses special remote control signals to operate various Quantum System features without the need for complicated and expensive digital systems. With QARC technology, you can operate features that are otherwise available only in Digital Command Control (DCC) plus some new features that are not yet available in DCC. QARC will allow you to: 1) turn on or off individual lights, 2) shut down and start up locomotives, 3) make up consists easily, 4) simplify Analog programming, 5) set System Volume or Mute while train is operating, 6) trigger Coupler Crash sounds, 7) operate prototype-like Air Brakes, 8) turn on Dynamic Brakes, 9) activate Status Report or Verbal Speedometer Readout, and operate many other features. The QARC System makes Analog operation more fun and more prototypical than DCC by eliminating the need to configure function keys. Every button on the QARC controller does exactly what it is labeled to do. The only major difference between QARC and DCC is that, with QARC, you are not able to independently operate multiple trains on the same powered track section at different speeds at the same time.

The QARC controller, called Quantum Engineer, can be added to your existing Analog DC power pack in less than five minutes. Wiring is simple: two wires go to the variable DC output from the power pack and two wires go to the track. All features on the power pack remain the same including throttle and reverse switch control. See the QSI web site at <http://www.qsiindustries.com> for further information.



Analog Programming

The Steam Locomotive can be Programmed Using a Standard Power Pack.

All advanced operations are easily programmed using your standard HO power pack. After entering programming (described below), various features are selected and operated by using the direction switch¹⁵.

Program Option #'s (POP's ¹⁶)	Option Name (Default Value)	Message ¹⁷ when Entering Option	Option Description
1	System Volume ¹⁸ (16, Max)	"Volume equals X"	Sets System volume (17 levels) where level 16 is maximum volume and level 0 is off.
2	Load (0, No Load)	"Load equals X"	Selects the starting and stopping inertia for both Regulated Throttle Control (RTC) and Standard Throttle Control (STC). Level 0 (no load), Level 1-15, increasing Load with acceleration to full speed from 15 seconds to 210 seconds in RTC and from 3 seconds to 45 seconds in STC.
3	Helper (Normal)	"Helper equals" "Normal", "Lead", "Mid", "End", "Pusher"	Selects Normal, Lead, Mid, End, or Pusher Helper in consists. Normal Locomotive has all sounds and lights enabled. Lead locomotive has all sounds enabled and Reverse Light disabled. Mid Helper has Whistle, Bell and all lights disabled ¹⁹ . End Helper has Whistle, Bell and all lights disabled except Reverse Light. Pusher has Reverse Light on all the time as train warning light. Whistle, Bell and all other lights are disabled.
4	"Direction" (Normal)	"Direction equals X"	Selects if the features associated with the locomotive's direction are "Normal" or "Reverse".
5-7	Reserved	Reserved	
8	V-Start (8.5v)	"V-Start equals X"	Sets track voltage where locomotive will leave Neutral. (See Example below)
9	V-Max (12v)	"V-Max equals X"	Sets track voltage where full power is applied to motor.
10	Throttle Mode (RTC)	"Throttle Mode equals X"	Selects between and Regulated Throttle Control (RTC) Standard Throttle Control (STC).
11	Programming Reset	"Warning - about to reset"	After next Quick or Slow Operation, Bell rings ²⁰ followed by a hoot to indicate locomotive is returned to factory default condition.
12	About	Model number	Each Quick or Slow Operation provides progressive information about Quantum Model Number, Software Version, and Software Release Date.
13	Whistle Volume	"Volume equals X"	Customizes Whistle Volume (16 levels). Max is 15.
14	Bell Volume	"Volume equals X"	Customizes Bell Volume (16 levels). Max is 15.
15	Chuff Volume	"Volume equals X"	Customizes Steam Exhaust Volume. (16 levels). Max is 15.
16	Blower Volume	"Volume equals X"	Customizes Blower Hiss Volume (16 levels). Max is 15.
17-19	Reserved	Reserved	
20	Air Brakes Volume	"Volume equals X"	Customizes Air Brake Air Release Volume (16 levels). Max is 15.
21-25	Reserved	Reserved	
26	Pump Volume	"Volume equals X"	Customizes Air Pump Volume (16 levels). Max is 15.
27	Air Let-off Volume	"Volume equals X"	Customizes Long Air Release Volume (16 levels). Max is 15.
28	Short Air Let-off Volume	"Volume equals X"	Customizes Short Air Let-off Volume (16 levels). Max is 15.
29	Reserved	Reserved	
30	Squealing Brakes/Flanges Volume	"Volume equals X"	Customizes Squealing Brake/Flanges Volume (16 levels). Max is 15.
31	Reserved	Reserved	
32	Coupler Volume	"Volume equals X"	Customizes All Coupler Sound Volumes (16 levels). Max is 15.
33-45	Reserved	Reserved	
46	Dynamo Volume	"Volume equals X"	Customizes Steam Electric Generator (Dynamo) Volumes (16 levels). Max is 15.

¹⁵ Programming is even simpler using a Quantum Engineer Controller (see previous section on page 6).

¹⁶ POP is short for "Program Option".

¹⁷ The verbal programming responses (such as "Enter Programming" etc.) have a minimum volume setting to provide programming information even when the system volume is turned all the way off.

¹⁸ You can set volume with the Manual Volume Control or with Programming or both. The Manual Volume Control will determine the range of volume control under Programming; that is, if you turn the Manual Volume Control down to say, 50%, you will not be able to increase the volume above the 50% value using Programming.

¹⁹ Some lights that are not controlled by the Quantum System may remain on.

²⁰ Bell will not be heard on models without Bell feature.

47	Pop-Off Volume	"Volume equals X"	Customizes Steam Electric Generator (Dynamo) Volumes (16 levels). Max is 15.
48	Blow Down Volume	"Volume equals X"	Customizes Steam Boil Blow Down Volumes (16 levels). Max is 15.
49	Injector Volume	"Volume equals X"	Customizes Water Injector Volumes (16 levels). Max is 15.
50	Reserved	Reserved	

Where "X" is the current value of the Program Option. Defaults are shown in parenthesis along with the option name; defaults for volume levels are listed on the Steam Model Specification sheet included with your locomotive.

Entering Programming

Use this simple sequence to enter Programming using the direction switch.

1. Apply power and turn up the throttle to hear the sound system come on.
2. Within five seconds of powering up, turn on the Bell²¹ with a **Quick** flip-and-back operation.
3. Within three seconds of the Bell turning on, turn the Bell²² off with a second **Quick** flip-and back operation.
4. Within three seconds, turn the Bell back on again with a third **Quick** flip-and-back operation.

If you delay too long after power has been first applied, the opportunity to enter Programming will time out and you will need to start again by shutting off and reapplying track power.

Once you perform the three Bell operations after applying power, the Bell will shut off automatically and you will hear "Enter Programming" and the Headlight and tender Reverse Lights will flash alternately off and on.

Scrolling through the Program Options

- After entering Programming, you will hear an announcement of the first Program Option, "Option 1 - System Volume".
- To access other Program Options, simply flip the direction switch to the opposite position and leave it there. Listen as each option number is announced in order.
- When you hear the Option Number you want, flip the direction switch back and leave it there. After you stop at an option you will hear the option number and name announced. When you are scrolling through and stopping at Program Options, **you are not making any changes**. To make changes you must actually **enter** the Program Option.

Note: If you accidentally go to a higher option number other than the one you wanted, simply turn the power off, re-enter Programming and start again²³. Once you reach the last Program Option, it will continue to announce the last option number.

Entering a Program Option and Making Changes

After the verbal announcement of a Program Option, you can enter that option by performing a **Slow** or **Quick** flip-and-back operation of the direction switch²⁴. Upon entering a Program Option, you will hear the current setting for that option. For unused Program Options, you will hear "Reserved". For any volume option, you will hear "Volume equals X" (where "X" is its current volume level setting). After a moment, you will hear the sound playing at its current volume²⁵.

Note: It is easy to distinguish between doing a **Quick** and **Slow** operation. When you flip the direction switch to do a **Slow** operation, wait until you hear a low level "hiss" sound from the locomotive and then immediately flip the direction switch back. To do a **Quick** operation, make sure you flip the direction switch back before you hear the "hiss" sound.

Note: Entering a Program Option does not change the settings for that option; it only provides information about its current value. After entering the Program Option, additional Slow or Quick flip-and-back operations will program new settings as described in the above table. For all level adjustments, a Quick operation will decrease one level while a Slow operation will increase one level.

Note: Since "System Volume" is the first Program Option, you can use Quick or Slow operations immediately after entering Programming to change the System Volume.

Moving on to Other Program Options or Leaving Programming

- Flip the direction switch at anytime to the opposite position, and leave it there. The Quantum will first return to and announce the current Program Option and then automatically advance to on to higher options.
- Exit Programming anytime you want by turning the power off and back on again.

For more information, download the Quantum Analog Reference Manual (Version 3) from <http://www.qsindustries.com>

21 If your locomotive does not have the Bell feature, you will only hear a single bell ding to indicate you have entered the Bell state.

22 If your locomotive does not have the Bell feature, you will hear a double ding to indicate you have left the Bell state.

23 If you have a Quantum Engineer, you can move both back and forth through Program Options.

24 If you have a Quantum Engineer, Quick and Slow operations are done with specific program buttons.

25 Setting any volume in Analog will also apply to DCC and vice-versa.

Example 1: Setting Throttle Mode (Program Option # 10)

This will determine whether your locomotive uses Regulated Throttle Control (RTC) or Standard Throttle Control (STC).

- Enter Programming after powering up your locomotive by turning the Bell on, then off and then on as described above.
- After the “Enter Programming” followed by “Option One - System Volume” announcement of the first Program Option, flip the direction switch and leave it there. You will hear the announcement “Option 1, 2, 3 ... etc.”. Stop when you hear “ten” by moving the direction switch back. You will hear “Throttle Mode”.
- Use a **Slow** or **Quick** operation of the direction switch to enter this option. If the throttle mode is at its default value (RTC), you will hear “Mode equals Regulated;” otherwise, you will hear “Mode equals Standard.”
- Use a **Slow** or **Quick** operation of the direction switch to change the Throttle Mode. Repeated **Slow** or **Quick** operations will cause the Throttle Mode to alternate between its two possible values, “Regulated” and “Standard”.
- Once you have selected the Throttle Mode you wish to use, turn the throttle off. When you then power up again, your locomotive will be using the Throttle Mode you have just selected.

Example 2: Setting V-Start (Program Option # 8)

This option will determine the voltage (and throttle position) at which your locomotive will leave Neutral and start moving.

- Enter Programming after powering up your locomotive by turning the Bell on, then off and then on as described above.
- After the “Enter Programming” followed by “Option One - System Volume” announcement of the first Program Option, flip the direction switch and leave it there. You hear the announcement “Option 1, 2, 3 ... etc.”. Stop when you hear the number “8” by moving the direction switch back. You will hear “V-Start”.
- Use a **Slow** or **Quick** operation of the direction switch to enter this option. You will hear “V-Start equals X” where “X” is the track voltage value currently set for leaving Neutral”.
- Use a **Slow** or **Quick** operation of the direction switch to activate this option. Hear the message “Set throttle to V-Start”. After three seconds the voltage will be announced²⁶. If you move the throttle, the new track voltage value is announced a few seconds later.
- Once throttle is set, use a **Slow** or **Quick** operation of the direction switch to start the V-Start voltage setting procedure. The locomotive will move²⁷ at a slow speed and the Bell will ring continually for about 25 seconds²⁸, indicating the correct value is being calculated. If you choose a very low voltage setting, be patient. If the locomotive does not move during the procedure, return to the beginning of this option²⁹ or start over and chose a slightly higher throttle setting.
- At the end of the process, the locomotive will stop moving and the Whistle will hoot, signifying the end of the operation and you will hear the message “V-Start = X” where “X” is the new setting.
- To leave Programming, turn the throttle off, and then power up for normal locomotive operation.
- Or continue to V-Max by moving the direction switch and waiting for the next Programming Option to be announced.

Note: The final value of V-Start may decrease from the original voltage reading because resistance in the power pack or pickups will drop the voltage slightly during the calibration procedure.

Example 3: Setting V-Max (Program Option # 9)

V-Max is set in the same manner as V-Start except after entering this Program Option, you will hear “Set throttle to V-Max” which is the throttle position where you want the full track voltage to be applied to the motor (usually about 80% of full throttle)³⁰. Then do a **Quick** or **Slow** operation to start the V-Max setting procedure. Like V-Start, the bell will ring continually³¹ until the voltage is set followed by a Whistle hoot to indicate the procedure is finished. Setting V-Max is much quicker than V-Start.

Note: During the V-Max setting, the locomotive will not move as it does under V-Start.

Note: When double heading your Quantum equipped locomotives³², make sure that both locomotives have similar speed/throttle characteristics by adjusting V-Start and V-Max to prevent them from fighting each other.

26 Quantum systems have a built in voltmeter that measures the track voltage and announces its value verbally. Depending on the power pack, this voltage may be slightly different than values measured by an external meter. However, since the Quantum Voltmeter uses its own values for throttle levels, it is the correct value for the system.

27 For earlier Quantum locomotives, the locomotive will only move at the very end of the V-Start calculation.

28 If the locomotive model does not have a bell feature, you will hear only a single ding indicator at the start of the process.

29 See section above: Moving on to Other Program Options or Leaving Programming.

30 V-Max should not be set too low when using RTC. For most MRC™ power packs, the best choice for V-Max is about 1.5 volts below the highest throttle setting as determined by the Quantum built-in Voltmeter.

31 If the locomotive model does not have a bell feature, you will hear only a single ding indicator at the start of the process.

32 Do not double-head Quantum equipped locomotives with standard locomotives and then operate the Whistle or Bell while locomotives are moving. The standard locomotive will reverse direction and fight with the Quantum equipped locomotive.

DCC Operation

These steps will allow you to start operating your Quantum equipped Steam Locomotive immediately using any DCC system that is compatible with the applicable NMRA DCC specifications.

1. Select locomotive number 3.
2. Set your DCC controller to 128 (preferable) or 28 (acceptable) speed step range.
3. Start your locomotive immediately by pressing the F6 DCC function key³³ to hear the locomotive's Start Up sounds. The Directional Lighting System (Headlight, tender Reverse Light and Mars light³⁴) will be off. Use the FL or FO key to turn on the Directional Lighting³⁵.

When you reduce the throttle to zero, the locomotive will automatically enter Neutral when the locomotive stops. You will hear a Short Air Let-off when the locomotive stops moving and a Long Air Let-off about one second - later followed by Air Pumps and other background sounds³⁶. The Directional Headlight will go dim. If your steam locomotive has a Quantum Mars light, it will stop pulsing and go dim and the front headlight will turn off in Neutral. If you locomotive has QSI multicolored Marker Lights, they will go to red.

The direction of your locomotive will change when you press the direction key on your DCC throttle.

Function Keys

The following table lists features that have been pre-assigned to your DCC function keys. Operation of these keys can be different in the Neutral state (locomotive stopped) and the motive states (locomotive moving in Forward or Reverse). After you have selected your locomotive, simply press any of the function keys listed below to produce the described effects.

Function Key*	Forward and Reverse	Neutral
F0 or FL or Headlight	Directional Lighting on or off	Directional Lighting on or off
F1	Bell on or off	Bell on or off
F2	Whistle or Whistle with Doppler Effect (see below)	Whistle on or off
F3	Coupler Crash/Coupler Fire	Coupler Arm or Coupler Fire
F4	Blower Hiss on or off	Blower Hiss on or off
F5	Dynamic Brake function on or off	Dynamic Brake function on or off ("Disconnect" only)
F6	Initiate Doppler Effect	Start Up
F7	Brake Squeal/Flanges and Air Brakes	Brake Set - Long Air Let-off
F8	Audio Mute on or off	Audio Mute on or off
F9	Short Air Let-off	Shut Down (three separate stages)
F10	Locomotive's Verbal Speed Readout in SMPH.	Locomotive's Verbal Status Readout
F11	Short Air Let-off (Number Boards)**	Blow Down (Number Boards)
F12	Short Air Let-off (Cab Lights)	Water Injector (Cab Lights)

* Quantum supports the new NMRA 0-12 function key standard; the old 0-8 standard is not supported.

** Features in parentheses indicate alternate assignments when available.

If you have a DCC command station that supports only the older 0 to 8 function key standard, you will have no way to initiate Shut Down in Neutral with these pre-assigned feature to function key mappings. There is an interim solution to this problem; Swap the features assigned to the F7 and F9 outputs in Neutral by doing the following:

1. Set CV49 to 9, set CV50 to 1, and set CV53 to 145. Now F7 in Neutral controls Shut Down.
2. Set CV49 to 11, set CV50 to 1, and set CV53 to 9. Now F9 in Neutral controls Long Air Let-off.

Directional Lighting Operation (FO or FL or Headlight)

The FL (or FO, or Headlight) key toggles the Automatic Directional Headlight/Reverse Light/Ditch Lights/Mars Light System³⁷ on or off.

The defaults for Headlight/Reverse Light (Reverse Headlight) and optional Ditch Lights and Mars Directional Lights are off; default for Marker Lights are on. When toggled on, the Directional Lights³⁸ come on according to the table below.

³³ It does not need to be F6; any function key or speed command for a locomotive that is not in Shut Down will activate the locomotive.

³⁴ Not all locomotives have the Mars light feature.

³⁵ Some lights such as firebox light, cab light, and number board lights may not be controllable by the Quantum system and remain on all the time.

³⁶ Neutral sounds also include boiler Pop-Off, Water Injector and boiler Blow Down that turn on and off randomly for random periods of time.

³⁷ Explicit lighting control features for Headlight, Reverse Light and optional Ditch Lights, Mars Light or Marker Lights can be assigned to DCC function outputs. (See QSI DCC Reference Manual, version 3)

³⁸ The Quantum System uses constant voltage lighting that is independent of track voltage.

Directional Lighting Operation in DCC and Analog including Optional Mars Light and Marker Lights.

	Forward	Neutral from Forward	Reverse	Neutral from Reverse
Headlight	On	Off	Off	Off
Reverse Light	Off	Off	On	Off
Mars Light	Strobing	Dim	Dim	Dim
Front ³⁹ Marker Lights ⁴⁰	White	White	White	White
Rear Marker Lights	White	White	White	White

Note: If your locomotive does not have Mars Light, the Headlight will be dim (instead of “Off”) in all states except Forward where it will be bright.

Note: Reverse light will not come on until dynamo is completely revved up.

Coupler and Coupler Crash Sounds (F3)

There are two ways to use the F3 key.

- As your locomotive is about to couple up to a string of cars, press the F3 key to trigger the crashing sound of locomotive coupling. Use the F3 key again as the locomotive moves out to trigger the same sound as the slack is taken up in the cars.
- Use the F3 key in Neutral to produce uncoupling sounds as you disconnect cars over uncoupler magnets. Press the F3 key once to produce the sound of the lift bar and coupling pin being raised. This first press also arms the uncoupling sound effect. Press the F3 key again while moving or in Neutral to trigger the sound of the coupler knuckle opening and air-lines parting.

Sound-of-Power™

Your steam locomotive will produce labored Chuffing sounds under acceleration and lighter Chuffing sounds under deceleration but only if CV 3, or CV 23 and CV 4, or CV 24 are set to non-zero positive values. The level of labored sounds is proportional to the values for these four CV's, and how much the throttle is increased or decreased.

Under acceleration, the Chuffing sounds will be more labored until the locomotive has achieved its final speed where it will then produce standard sounds appropriate to its throttle setting. Under deceleration, the locomotive Chuffing sounds are less labored until it achieves its final speed where it will again produce standard steam sounds appropriate to its throttle setting.

Note: If your locomotive has two sets of drivers, you will hear two sets of steam Chuffing sounds that will go gradually in and out of synchrony.

Whistle and Bell Buttons (F2, F1)

Some DCC controllers have separate whistle and bell buttons along with function keys assigned to whistle and bell operation. The bell is usually assigned to F1 and the whistle is usually assigned to F2. The F2 key behaves differently than using the whistle button.

- Pressing the F2 key and releasing it will cause the whistle command to come on and stay on, until you press F2 again.
- Pressing the whistle button will blow the whistle only as long as you are holding the button down.

Pressing the F1 key and releasing it will cause the Bell to come on and stay on, until you press F1 again⁴¹. There is no difference in operation between the bell button and its corresponding function key.

Doppler Operation (F6)

With DCC, you can trigger the Doppler Effect by quickly interrupting the whistle signal in the same way as described under Analog Operation. Or, you can use the function key (F6) assigned to the Doppler Effect.

- Start the Whistle and/or Bell by pressing and releasing their function keys⁴².
- Press F6 to hear the Doppler shift. A few seconds after the whistle button is turned off with the F2 key the steam locomotive sounds return to normal⁴³.

Squealing Brake and Flange Sounds (F7)

- Quantum provides automatic brake squeal as a locomotive slows to a stop. The operator can also control squealing sounds for continuous and variable brake sounds for protracted stops or to simulate the sounds of squealing wheel flanges on curved track.
- Squealing Brakes come on automatically when the speed is reduced from high-speed travel (over 40 smph) to less than 20 smph.

³⁹ Side Marker Lights, when on, are always red.

⁴⁰ Marker Light feature may not be multicolored on some models. If so, Marker Lights will be white in all directional states.

⁴¹ If the prototype locomotive does not have a bell, your model will not have the Bell feature. However, all Quantum locomotives have a “Bell State” used for a number of Quantum operations. The Bell State is turned on and off with the F1 key. You will hear a single bell ding when you enter the Bell State and a double ding when you leave the Bell State.

⁴² If you do not turn on either Whistle or Bell, the Doppler shift will still occur but will be less dramatic.

⁴³ If the Bell was on, it will shut off prior to sounds returning to normal. If you do not have the Bell feature, but the Bell State is on, it will turn off prior to locomotive sounds returning to normal.

- Pressing the F7 key when the locomotive is moving at any speed will manually activate Squealing Brake sounds, and repeated pressings while the Squealing Brake sounds are occurring will continue the sounds uninterrupted.

Note: If you slow the locomotive too quickly, the brake sounds will terminate abruptly when the locomotive stops and enters Neutral.

Note: If you lower your throttle to speed step 0 on a moving locomotive, the F7 key will apply Air Brakes to slow the locomotive. See next section.

Air Brakes (F7)

If you have selected any non-zero deceleration inertia or momentum value in CV 4 and/or CV 24, the F7 key can be used to apply Air Brakes to stop the locomotive more quickly than it would normally stop from the inertia settings⁴⁴. To use Air Brakes:

- Turn the throttle down to speed step 0 on a moving locomotive; this enables the F7 key to act as a brake.
- Press the F7 key. Hear a brief brake squeal sound and air being released from the brake lines continually. The longer the air is released the greater the braking action.
- Press the F7 key again to stop the air release. The train will continue to slow at the last braking value.
- If you want to apply more braking, press the F7 key again to release more air. When you reach the desired amount of braking, press F7 again to stop the air release.

Note: If you continue to release air (for over 24 seconds totally) all the pressure will be released and brakes will be on full; you will hear no further air release sounds.

- Turn up the throttle to any value above 0 to release the brakes; this action returns the locomotive's deceleration to a value determined by the sum of CV 4 and CV 24.
- If the locomotive is in Neutral when the F7 key is pressed, a Long Air Let-Off sound simulates setting the brakes. However, no braking effect is activated⁴⁵.

Note: If the throttle is set to any speed step except 0, Air Brakes are not enabled; instead the F7 key will now manually activate Squealing Brake/Flange sounds but will not affect the locomotive's deceleration.

Automatic Features with "Take Control" Operation

The Quantum System allows the operator to take control of certain automatic features by using their associated function key or keys. Once you "Take Control", the features will no longer have automatic operation and you will control their operation and their state with their function key commands. Automatic and Take Control operations are described in the table below.

Steam Locomotive "Take Control" Operation

	Automatic Operation			Take Control	
	Forward	Reverse	Neutral	Function Key	Operation
Steam Blower	Off after 10 sec	Off after 10 sec	On after 10 sec	F4	Toggles Steam Blower

Example: Take Control of Automatic Steam Blower

- Take Control of Automatic Steam Blower with the F4 key to stop automatic operation and control whether the Steam Blower is on or off.

Regardless of the state of the Blower (on or off), if you press the F4 key, the steam Blower hiss will be set to on if the F4 key is "1" and off if the F4 key is "0" and Automatic Control will be disabled. Thereafter, the steam Blower hiss will respond only to the state of the F4 function. Automatic Control will be restored if the power is shut down and reapplied or if the F6 Start Up key is double pressed in Neutral (see the description of Start Up on the following page).

Three Stages of Steam Locomotive Shut Down: 1. Disconnect, 2. Standby, 3. Total Shut Down (F9)

Locomotive Shut Down has three distinct stages that you can control. Each stage is entered by double pressing the F9 key⁴⁶.

Stage One: Disconnect

- Double press the F9 key in Neutral to enter Disconnect. You will hear a Long Air Let-off.
- To leave Disconnect, either double press the F6 Start Up key described in the Start Up section or double press the F9 key again to reach the next stage of Shut Down, Standby.

If you double press the F9 key in Neutral, the electric motor drive will be disconnected. Once you hear the Long Air Let-off after entering Disconnect, which represents the locomotive's reverse lever being placed in the neutral position, the throttle can be moved up and down

⁴⁴ CV4 and CV24 determine the deceleration rate. Applying the brakes increases the deceleration rate temporarily.

⁴⁵ If the brakes are set in Neutral, turning up the throttle automatically releases the brakes.

⁴⁶ Double pressing ensures that Shut Down stages are not entered or exited accidentally. Double pressing is defined as two F9 commands sent within two seconds. Note that the F9 key may have to be pressed three times, due to the DCC command station and locomotive having different initial states for F9.

without the steam locomotive moving. Instead, you will hear the sound of steam gradually being vented through the throttle. All function keys are active in Disconnect.

Note: There is no effect on the throttle Sound-of-Power from Dynamic Brakes being on in Disconnect as there is in diesels.

Stage Two: Standby

- Double press the F9 key while in Disconnect to enter Standby. You will hear a Long Air Let-off followed by Directional Lighting turning off and steam Blower shutting down. The motor will remain disconnected. Air Pumps will remain on. In Standby, the locomotive will not respond to throttle or function keys⁴⁷. The three exceptions are the F6 Start Up Key, the F8 Mute Key (described below) and the F10 Status Key (described below).
- To leave Standby, either double press the F6 Start Up Key described in the Start Up section, or double press the F9 key again to reach the final stage of Shut Down, Total Shut Down.

Note: Standby is ideal for leaving your locomotive(s) running on a siding. It leaves the locomotive steamed up with low-level background sounds, but the locomotive will not respond to accidentally changing the throttle setting or pressing the function keys.

Stage Three: Total Shut Down

- Double press the F9 in Standby to enter Total Shut Down. You will hear the Long Air Let-off.
- To leave Total Shut Down, double press the F6 key.

The Air Pumps will turn off, followed later by the sounds of Pop Off operating for about ten seconds followed by hiss that gradually trails off to silence. In Total Shut Down, the locomotive will not respond to throttle or function keys. The two exceptions are the F6 Start Up Function Key (described below) and the F10 Status Key (described below).

Note: Total Shut Down allows the operator to take the locomotive “off line” (turn off sounds, lights, ignore throttle settings and function commands) independent of the operating session; that is, the locomotive will still be “off line” when power is reapplied for the next operating session, irrespective of whether this next session is Analog (conventional DC) or DCC.

Note: If power is turned off at any stage of Shut Down (Disconnect, Standby or Total Shut Down) or during a Shut Down procedure, the locomotive will remember the last Shut Down stage it was at during power down, and the locomotive will power up in the same stage. If Start Up is initiated during any of the above Shut Down procedures, Shut Down is aborted and the locomotive returns to normal operation.

Dynamic Brakes (F5)

Prototype steam locomotives do not have dynamic brakes. However, the Dynamic Brake function has been included to make the Quantum steam locomotive consistent with other Quantum equipped locomotives in consists.

- Pressing the F5 key will set the steam exhaust Sound-of-Power to the lowest setting allowing the steam labored sounds to be consistent⁴⁸ with other locomotives that do have Dynamic Brake sounds in multiple unit consists.
- Pressing the F5 key in Neutral will have no Dynamic Brake effect.

Dynamic Brakes automatically turn off when entering or leaving Neutral, when locomotive speed drops below 7 smph⁴⁹, or when the throttle is turned up. Dynamic Brakes cannot be turned on in Forward or Reverse unless the locomotive speed is over 8 smph.

Note: In contrast to Air Brakes (F7), Dynamic Brakes do not increase the deceleration rate specified by CV 4 and CV 24.

Start Up (F6)

If your Quantum equipped steam locomotive is in any stage of Shut Down, you can return your locomotive to normal operation by double pressing⁵⁰ the F6 key. Start Up will be different for each stage of Shut Down, but all will start up with a Long Air Let-off and will enter normal operation.

Start Up from Disconnect: If you double press the F6 key in Disconnect, the steam locomotive will produce a Long Air Let-off and the locomotive will enter normal operation.

Start Up from Standby: If you double press the F6 key in Standby, the steam locomotive will produce a Long Air Let-off, the Dynamo will start up and Directional Lighting will turn on (if previously on) and then the locomotive will enter normal operation.

Start Up from Total Shut Down: If you double press the F6 key in Total Shut Down, the steam locomotive will produce a Long Air Let-off, the Dynamo will rev up and the Directional Lighting will turn on (if previously turned “on”) followed by the Air Pumps starting up, the steam Blower turning on and then the locomotive will enter normal operation.

Note: During any of the Start Up procedures, none of the function keys are active. If the throttle is turned up from zero during any of the above Start Up procedures, the Start Up procedure will abort and the locomotive will enter normal operation.

⁴⁷ Pressing a function key will only produce a Short Air Let-Off.

⁴⁸ It would be inconsistent for a steam locomotive to be working at full Sound-of-Power while Dynamic Brakes are being applied to other locomotives within the same consist.

⁴⁹ Dynamic Brakes on prototype locomotives are less effective and are seldom used at low speeds.

⁵⁰ Double pressing ensures that Start Up is not entered accidentally. Double pressing is defined as two F6 commands sent within two seconds. Note that the F6 key may have to be pressed three times, due to the DCC command station and locomotive having different initial states for F6.

Note: Whenever a Start Up command is sent, regardless of whether the locomotive is in Shut Down or operating normally (in Neutral), the Quantum System will automatically restore all Automatic Control.

Mute (F8)

The Quantum System allows you to reduce the System Volume to a lower level or increase it back to its original setting using the F8 function key. This capability is useful when you need to reduce the sound to engage in a conversation or to answer the phone. If you have many trains operating at once, you can reduce the volume on all those that are running in the background of the layout and increase the volume of the closest locomotive. The Mute feature changes the sound gradually over a second or two, which allows the sound to increase or decrease realistically as the locomotive approaches or recedes from the observer.

- Press the F8 key in Neutral or Forward/Reverse to gradually decrease or increase the locomotive's volume.

Note: Mute state is not maintained if power is turned off and then turned back on; the locomotive will return to full volume setting.

Note: Mute is shut off if the Status F10 key is pressed to allow clear audio reporting (see Status below)

Note: Mute Volume can be programmed in CV 51.1.

Status (F10)

The Quantum System provides verbal information about the locomotive's current operating state when the locomotive is in Neutral or the locomotive's current speed in scale miles per hour when the locomotive is moving.

- Press the F10 key in Neutral; the locomotive will verbally report first its currently enabled long or short DCC address followed by its consist ID (if it has one) followed by its Shut Down state, if any (Disconnect, Standby or Shut Down).
- Press the F10 key in Forward or Reverse; the locomotive will verbally report the locomotive's speed in scale miles per hour.

Note: When Status Report (or Verbal Speedometer Readout) is activated, mute is shut off and the locomotive's sounds will reduce to one half their current volume settings during the verbal report. Locomotive sounds return to normal non-muted volume when the report has ended.

Note: In a consist, all locomotives will simultaneously report their status when the F10 key is pressed, unless disabled in CV22.

Function Key Operation in Neutral

Some function keys used in Forward and Reverse will have different effects when used in Neutral:

- The F7 key produces Squealing Brake sounds or applies brakes for a moving locomotive but produces a Long Air Let-off in Neutral.
- Pressing F6 results in Doppler shift for a moving locomotive but activates Start Up in Neutral.
- Pressing F9 produces a Short Air Let-off in a moving locomotive but activates Shut Down in Neutral.

Note: Whistle, Bell, Doppler, Squealing Brakes and Neutral sounds are described in detail on page 18, in the *Quantum System Sounds* section of this manual.

DCC Programming

Most DCC command stations currently available will program Quantum equipped locomotives in Service Mode⁵¹ on a programming track or Operations (Ops) Mode on the main track. In Service Mode, your locomotive (if queried) will report back CV values to your command station. In Ops Mode, reports are verbal using the locomotive sound system.

Changing the System Volume Electronically in CV 51.0

You can change the volume either manually (as described in the *Special Operation and Troubleshooting* section) or electronically using QSI CV 51.0 in DCC⁵². To change volume in Service or Ops Mode, do the following:

- Set CV 49 to 0.⁵³
- Enter the System Volume in CV 51. The System Volume can be set to any value between 0 (no sound) and 127 (100%). The default System Volume is 127.

Note: When you change the System Volume in Ops Mode, you will immediately notice the change in volume.

Changing the Mute Volume Electronically in CV 51.1

To change the Mute Volume in Service or Ops Mode, do the following:

- Set CV 49 to 1.
- Enter the Mute Volume in CV 51. The System Volume can be set to any value between 0 (no sound) and 63 (100%). The default Mute Volume is 0.

Note: When you change the Mute Volume in Ops Mode, and the locomotive is muted, you will immediately notice the change in Mute Volume.

Note: The Mute Volume level will be the smaller of either the Mute Volume setting or one half the current System Volume. In other words, the Mute Volume will never be more than one half of the System Volume.

Enable/Disable Whistle Triggered Doppler Shift (CV 51.2)

- Set CV 49 to 2.
- Set CV 51 to 0 to disable Whistle Triggered Doppler, set to 1 to enable Whistle Triggered Doppler.

Changing Individual Sound Volumes (CV 52.X⁵⁴)

To change the volume of Individual Sounds listed in the table below do the following⁵⁵:

- Set CV 49 to the Primary Index for the individual sound from the table below.
- Enter Volume level in CV 52 as follows: “0” = No sound, “1 – 15” sets volume from the lowest level at “1” to the highest at “15”, with volume levels at 2db increments.

Primary Index entered into CV 49	Individual Sound
0	Whistle
8	Bell
10	Chuff 1 (steam exhaust)
11	Chuff 2 ⁵⁶
16	Pump 1 ⁵⁷
17	Pump 2
19	Blower (hiss)
21	Long Air Let-off
22	Short Air Let-off
24	Squealing Brakes/Flanges
26	Dynamo

51 If your DCC command station will not program in Service Mode, check with the command station manufacturer; some companies will give you a free upgrade. Also, see Special Operation and Troubleshooting on page 20.

52 System Volume changes in DCC also apply to Analog and vice-versa.

53 In Ops Mode, you will hear the value spoken out when changing the value of a CV.

54 'X' refers to the value in column 1 of the table, the Primary Index number that will be entered into CV 49.

55 Setting any Individual Sound Volumes in DCC will also apply to Analog and vice-versa.

56 Volume setting for Chuff 1 and Chuff 2 will also apply to Analog. However, since there is only one setting for Chuff Volume in Analog, POP 26 will change the volume level of Chuff 1, which will also apply to Chuff 2. When returning to DCC, both Chuff Volumes will be at the same value as set in Analog.

57 Volume setting for Pump 1 and Pump 2 will also apply to Analog. However, since there is only one setting for Pump Volume in Analog, POP 26 will change the volume level of Pump 1, which will also apply to Pump 2. When returning to DCC, both Pump Volumes will be at the same value as set in Analog.

29	Boiler Pop-off
30	Boiler Blow down
31	Water Injector
34	Coupler Sounds

See your *Steam Model Specifications* sheet for Individual Sound Volume default settings.

Chuff Interval Scale Factor (CV 56.12)

If the Chuff Sound is not exactly four per revolution or you want to change it to some other value, use the following procedure to change the Chuff interval⁵⁸.

- Set CV 49 to 12.
- Set CV 56 to any value between 0 and 255. Chuff rates are calibrated to be approximately the values shown in the table below. Adjust CV 56.12 value to be higher or lower than these recommended settings to decrease or increase the chuff rate.

Approximate Chuffs/Revolution	Scale Factor	CV 56.12 Value
8	.5	16
4	1	32
2	2	64
1	4	128

Reset all ⁵⁹ CV's to Factory Default Values (CV 56.128.255)

Note: This does not affect Analog settings, except volumes.

- Set CV 49 to 128.
- Set CV 50 to 255.
- Set CV 56 to 113 ⁶⁰. In Ops mode, you will hear 3 hoots when reset is completed.

Special Procedure for Short or Extended Address Programming (CV 56.129)

If you cannot program your Short or Extended ID number in Service Mode and your DCC command station prevents you from setting either of these addresses in Ops Mode (using CV 1, or CV 17 and CV 18) use the following alternative procedures to program your locomotive ID's.

Alternate Procedure for Entering Short (Primary) Address in CV 56.129.1 in Ops Mode

- Set CV 49 to 129.
- Set CV 50 to 1.
- Set CV 56 to your Short Address (1 or 2 digits). Hear the address spoken back.
- If necessary, set CV 29, bit 5 to '0' (or set CV 29 to 6 which is factory default) to enable your new Primary Address.

Procedure for Entering Long (Extended) Address in CV 56.129.17 in Ops Mode.

- Determine the value of CV 17 and CV 18 for your Extended Address from the ID Table in your *Steam Model Specification Sheet* or follow instructions in CV 17 and CV 18 in the *Quantum DCC Reference Manual (Version 3)* to calculate a different ID number.
- Set CV 49 to 129.
- Set CV 50 to 17.
- Set CV 56 to the value of CV 17 from the table. There will be no verbal response.
- Set CV 50 to 18.
- Set CV 56 to the value of CV 18 from the table. Hear the new full Extended Address spoken out.
- Set CV 29, bit 5 to '1' (or set CV 29 to 38 ⁶¹) to allow operation with your new Extended Address.

⁵⁸ This setting applies to both DCC and Analog operation.

⁵⁹ Consult the Quantum DCC Reference Manual (Version 3) to learn how to reset different groups of CV's.

⁶⁰ "113" is QSI's Manufacturer's ID Number assigned by the NMRA.

⁶¹ Entering "38" leaves the other configuration settings in CV 29 at factory default, but changes the ID to Extended Address type.

Disable/Enable Verbal Announcements (CV 62)

In Ops mode, the Quantum System will automatically speak out the value of the CV you enter.

- To disable set CV 62 to 0⁶²; to enable set CV 62 to 1⁶³. Default is Enabled.

CV Inquiry with Verbal Feedback in Ops Mode (CV 64)⁶⁴

To inquire about the current value of any CV through Verbal Feedback in Ops Mode:

- Set CV 64 to the CV you wish to query. Hear the verbal message “CV ‘X’ equals ‘Y’”, where ‘X’ is the CV number and ‘Y’ is the value.

Note: If the CV has a Primary Index such as QSI CV nn.pp (where nn is the CV number and pp is the Primary Index), set CV 49 to pp before you set CV 64 to nn. For example, if you want to inquire about the Bell Volume, which is CV 52.8, set CV 49 to 8 and set CV 64 to 52. You will hear, “CV five two point eight equals ‘Y’ (where ‘Y’ is the current volume setting). If the CV has both a Primary and Secondary Index, such a nn.pp.ss, where ss is the Secondary Index, set CV 50 to ss in addition to setting CV49 to pp before you set CV 64 to nn.

Note: If you enter either ‘17’ or ‘18’ in CV 64, you will hear the full one to four digit Extended Address ID number spoken out.

Common NMRA Configuration Values (CV 29)

Each bit in CV 29 controls some basic operational settings for DCC decoders, including Extended Addressing, Speed Table Enable, Power Source Conversion, Lighting Operation, Locomotive Direction, and others. Quantum default for CV 29 is 6.

The following table provides some of the more common values for CV 29 for the features indicated.

Extended Addressing	Speed Tables	Power Conversion	28/128 Speed Steps	Reversal Direction	Decimal Value	Binary Value	Hex Value
			X		2	00000010	2
		X	X		6	00000110	6
	X		X		18	00010010	12
	X	X	X		22	00010110	16
X			X		34	00100010	22
X		X	X		38	00100110	26
X	X		X		50	00110010	32
X	X	X	X		54	00110110	36
			X	X	3	00000011	3
		X	X	X	7	00000111	7
	X		X	X	19	00010011	13
	X	X	X	X	23	00010111	17
X			X	X	35	00100011	23
X		X	X	X	39	00100111	27
X	X		X	X	51	00110011	33
X	X	X	X	X	55	00110111	37

For more information, download the *Quantum DCC Reference Manual (Version 3)* from <http://www.qsindustries.com>.

62 You will not hear “CV 62 = 0”.

63 You will hear “CV 62 equals 1”.

64 This option is not affected by CV 62 (Disable/Enable Verbal Announcements).

Quantum System Sounds⁶⁵

Steam Chuff: The familiar steam chuff comes from steam exhausted from the steam chest through the smoke stack, which creates a powerful draft to feed the fire. QSI Quantum Chuffing produces four distinct Chuff sounds per drive wheel set, a rhythm recognized by all steam fans.

Articulated Chuff: Articulated or Duplex steam locomotives have two sets of steam Chuff sounds that will go gradually in and out of synchrony. Most articulated locomotives had less weight over the front engine, which resulted in more slippage, causing the two engines to run at slightly different speeds.

Blower or Steam Locomotive Hiss: On a moving locomotive, the steam from the steam chest venting through the smoke-stack draws air through the fire box, keeping the fire healthy. When the locomotive is sitting still, blowers are often turned on to vent steam through the smoke stack to maintain the draft. Blowers were often turned off soon after the locomotive started out. The QSI steam Blower sound on steam locomotives will turn on gradually followed by a continual steam hiss.

Air Pumps: When a locomotive is sitting still, the pumps come on at a steady beat to replace the air lost from the brake air release and from pneumatically operated appliances. Once the pressure is up, the pumps only operate occasionally to maintain the pressure. Large steam locomotives may have more than one pump operating independently.

Appliance Air Release: Compressed air is used on locomotives for operating various appliances. You will hear either a Short Air Let-off or Long Air Let-off at various times.

Air Brakes: When prototype train brakes are applied, air is released from the brake lines to reduce the pressure. The more the pressure is reduced, the greater the braking. You will hear a continual air release sound from the steam locomotive model as braking is continually increased. The longer the air is released, the quicker the steam locomotive model will slow down. Once all the pressure is released, the locomotive will continue at maximum braking which can still require a long stopping distance depending on your Load settings. *DCC and QARC⁶⁶ Only.*

Brake Squeal: You can hear the brakes squeal on prototype locomotives when they are moving slowly. This sound can become quite loud when the wheels are just about to stop turning. Listen for automatic Squealing Brake sounds at slow speeds and the final distinctive squealing sounds as the Quantum equipped steam locomotive slows to a stop.

Dynamic Brakes: Steam locomotives do not have Dynamic Brakes. When steam locomotives are operated today, they are often coupled to a diesel to provide dynamic brakes on down grades. If a Quantum steam locomotive is coupled to a Quantum diesel, and Dynamic Brakes are activated, the diesel Dynamic Brake effect will start up and the steam locomotive labored chuffing will reduce at the same time. Since prototype dynamic brakes are relatively ineffective at low speeds, the Dynamic Brakes will shut off automatically below 8 smph and steam locomotive Chuff will return to normal. *DCC and QARC Only.*

Whistle: The Quantum System uses authentic locomotive sounds whenever possible. All Quantum Whistles are engineered by QSI sound experts to give you the most authentic effects. If you blow the Whistle briefly, you will produce a realistic short Whistle sound or "hoot". Some locomotive models have special Whistle Endings to allow the whistle to be "played" when desired.

Bell: Steam locomotives can have either a pull bell or pneumatically operated mechanical bell. With pull bells you will hear a different sound as the bell swings forward and backward producing the familiar ding-dong effect. Pneumatic bells produce a very repetitive ring and often much faster ring rate than a pull bell. During turn-on in Neutral, you will hear the pneumatic clapper gain greater throw with each stroke until it finally strikes the Bell. During shut down in Neutral, you will hear the Bell sound fade out for either pneumatic or pull Bells.

Doppler Run-by: The locomotive sounds get louder as the train approaches, then immediately drop to a much lower pitch and lower volume as the train passes by. With a little practice you can activate the Doppler Effect exactly when and where you want. Doppler pitch change is based on the speed of the locomotive, so the sounds change more dramatically when the locomotive is running faster. After the Doppler shift has occurred and the Whistle is no longer being blown, the Bell shuts off automatically and locomotive sounds return to normal.

Coupler: To give you the most authentic coupler sounds, QSI has identified three distinct types of coupler activity. The first is when the coupler is Armed where you will hear the clanking sound of the coupler lift bar and coupler pin raising. The next is Firing the coupler, where you hear the opening of the coupler with the hiss of the air-lines parting. The third sound occurs when the locomotive couples up to its load of cars, and you hear the Coupler Crash as all of the cars bunch together from the impact. *DCC and QARC only.*

Flanges: When a train enters a curve, the flanges on the wheels ride up on the inside of the rail and squeal. Recreate this squealing effect by pressing and releasing the Squealing Brakes/Flanges DCC function key or QARC Analog button quickly and repeatedly as necessary. *DCC and QARC only.*

⁶⁵ Not all features are included on every steam locomotive. Consult your Steam Model Specifications sheet for a list of features and sounds that apply to your locomotive model.

⁶⁶ QARC™ or Quantum Analog Remote Control™ uses special signals under Analog control to operate different Quantum features. With QARC, you can operate features that are currently available only in DCC in addition to features that are not yet available in DCC.

Steam Pop-off: If there is too much steam pressure in the boiler, special pop-off valves, or safeties, on top of the locomotive release the excess pressure in a fury of hissing steam that often will blow for 30' or more above the locomotive. This happens most often when the locomotive is sitting still, since the fire continues to build up steam that is not used. The Quantum Pop Off sound comes on for random lengths at random times in Neutral.

Steam Water Injector: The water used to make steam is replaced by water injectors at high pressure, to overcome the elevated pressure in the boiler. The sound of rushing water and steam hiss ends with a distinctive valve shut off. This sound comes on for random lengths of time and occurs randomly when the locomotive is in Neutral.

Steam Boiler Blow Down: As water evaporates, minerals and other residues settle to the bottom of the boiler. The fireman opens a valve to vent this material through a large pipe under the side of the cab onto the ground. Quantum's Blow Down sound occurs at random in Neutral for varying lengths of time.

Special Operation and Troubleshooting

For a full description, see the Troubleshooting section in the Quantum DCC Reference Manual (Version 3) at www.qsindustries.com.

With some Command Stations, using the whistle button to activate the Whistle, and, while this button is held down, activating the F6 Doppler Key, will cause the Whistle to shut off instead of causing a Doppler shift effect.

We have experienced intermittent and independent whistle signal interruption with some DCC command stations, causing unexpected Doppler shifts. If this happens frequently, you may want to disable the Whistle Triggered Doppler (CV 51.2).

Manual Volume Adjustment (Analog and DCC)

To adjust the volume by hand:

- Locate the Manual Volume Control (potentiometer) on the roof of your steam locomotive tender as shown in the *Steam Model Specification* sheet that was included with your model.
- Use a small screwdriver to turn the potentiometer clockwise to increase volume or turn it counterclockwise to decrease the volume.

Note: Volume can also be adjusted digitally using the programming methods described in the programming sections of this manual. However, if you turn the volume down using the Manual Volume Control, you will not be able to increase the volume using programming above the level set by the potentiometer.

Using the Quantum Reset Jumper to Return Your Locomotive to Factory Default Values (Analog and DCC)

In case your locomotive's sound and control system misbehaves and turning the power off for 15 seconds does not return it to normal operation, you can reset your locomotive to original factory values. The jumper⁶⁷ is located as shown in the *Steam Model Specification* sheet that was included with your model.

- Turn off the power.
- Remove the jumper by pulling it up.
- Reapply power, after a few seconds you will hear "reset".
- Turn the power off, reinstall the jumper. The locomotive has now been returned to original factory defaults including all DCC and Analog values.

High Voltage Circuit Breaker (Analog and DCC)

Your Quantum equipped steam Locomotive is designed to operate on normal HO track voltage supplied by most HO power packs. If track voltage exceeds 21.5 volts peak, the motor drive circuit will automatically shut down and the locomotive will coast to a stop. The Quantum System will alert you to the problem through a continuous series of Whistle hoots. This built in safety feature protects the Quantum Electronics and the electric motor from excessive voltage.⁶⁸

- To restart your locomotive, reduce the track voltage until the hooting stops and the motors re-engage.

Program Track Operation (DCC)

Your locomotive conforms to NMRA standards for program track operation. However, the Quantum sound system requires more current to operate than standard DCC decoders and may not respond to the limited program track power from some command stations. If you are unable to program in Service Mode on your program track, all CV's in your locomotive can be programmed in Ops Mode. You can also purchase from Tony's Train Exchange⁶⁹, a simple, inexpensive power booster (PowerPak™ by DCC Specialties) that will allow you to program on the program track with any DCC command station.

Reasons why Your Locomotive is Silent or will not Start (Analog and DCC)

In case your locomotive remains silent after power up and turning the power off for 15 seconds does not return it to normal operation, try the following suggestions to bring your locomotive back to normal sound operation.

- Make sure the locomotive has not been Muted with the F8 key.
- Check to see if your volume potentiometer or digital sound has been turned all the way down.

⁶⁷ On some locomotives a slide switch was used instead of a jumper.

⁶⁸ The high voltage circuit breaker will sometimes activate if the load (inertia or momentum) feature is used. Most power packs have substantial series resistance, which lowers the track voltage when the locomotive is drawing power. However, with a load setting, the locomotive does not require much power when it first starts moving. If the throttle is turned up all the way before the locomotive gains speed, the track voltage will be unusually high and can trigger the high voltage circuit breaker.

⁶⁹ Tony's Train Exchange; 1-800-978-3427; <http://www.tonystrains.com/>.

- You may have shut your locomotive down in DCC using the F9 key, **which will also shut it down in Analog**. Go back to DCC operation and start your locomotive with the F6 key⁷⁰. Once started, you can return to DC or DCC operation.
- If the above methods do not start your locomotive, use the jumper to reset your locomotive to factory default values as described above.

⁷⁰ It may take a couple of tries to get it started.

Sounds & Features Common to Analog & DCC	Analog Features*	DCC Features*
<p>Whistle or hoot Bell with shut down and turn on Effects (if so equipped) Steam Exhaust (chuff) Articulated Chuff (optional) Automatic Blower Hiss Doppler Shift Brake or Flange Squeal Neutral Sounds Long Air Release Short Air Release Air Pump Dual Air Pumps (optional) Sound of Power™ Neutral State (Idle) Directional Lighting Bright Headlight Reverse Light (optional) Cab Lights (optional)</p> <p>Manual Volume Control with Potentiometer Reset to Factory Default with Jumper</p>	<p>System Volume Programming Individual Sound Volume Control Regulated Throttle Control and Locomotive Inertia Helper Type: (Normal) Normal loco, Lead Loco, Mid Helper, End Helper. Pusher. Direction: (Normal) Normal/Reversed DC Power Pack Programming V-Max (12v) V-Start (8.5v)</p> <p>QSI QARC™ Operation** (with QSI QARC Controllers™)</p> <p>Air Brakes Flanges Dynamic Brakes Locomotive ID's. Consist ID's. Coupler Sounds Extended Shut Down Extended Start Up Explicit Lighting Control Controllable Flange Squeal Load on/off toggle Blower on/off toggle Verbal Locomotive Status Grade Crossing Signal Audio Mute System Volume Control and Additional Features</p>	<p>F0 or FL light control F1-F12 Function Keys 14/28/126 speed steps (28) Coupler Sounds Air Brakes Dynamic Brake Effect (for consists) Programming Modes Supported: Address Mode, Register Mode, Service Mode, Direct Mode, Ops Mode Long Form & Ops Mode Short Form NMRA™ CV's supported: 1 Primary Address 2 V-Start 5 V-High 8 QSI MFG's ID Number (113) 3-4,7,17-25,29,33-46,66-95 QSI CV's supported: 49 Primary Index 50 Secondary Index 51 Sound Control 51.0 System Volume 51.1 Mute Volume 51.2 Doppler (Enabled) 52 Individual Sound Volume Control 53 Function Output Mapping 56 QSI Configuration 56.12 Chuff Interval Scale Factor 56.128.n Reset 56.253 Version Build Information 62 Auto CV Verbal Feedback (enabled) 64 CV Inquiry Verbal Readout</p>

*Settings in parentheses indicate factory default. For factory defaults not listed here, see the Steam Model Specification Sheet included with your locomotive.

**QARC⁷¹ Technology allows commands to be sent to locomotives under Analog control to operate different Quantum features. With QARC technology, you can operate features that are otherwise available only in DCC plus features that are not yet available in DCC. The QARC controllers are inexpensive accessories that employ the QARC system. They can be added to your existing power pack to operate additional features on your Quantum⁷² equipped locomotive.

QSI Industries, Inc. Software License Agreement

1. Grant of License: QSI Industries, Inc. grants you, the owner, the right to use the software that is included with your Quantum system only with the locomotive that you purchased.
2. Copyright: The software is owned by QSI Industries, Inc. and is protected by United States copyright laws and international treaty provisions. Therefore, neither you nor anyone else may copy the software.

Proprietary Rights and Obligations

The structure and organization of the Software/Firmware are the valuable properties of QSI Industries, Inc. You will not make or have made, or permit to be made, any copies of the Hardware, Software/Firmware, code, or any portions thereof. You are not to modify, adapt, translate, reverse engineer, de-compile, disassemble or create derivative works based on the Hardware or Software/Firmware. Trademarks shall be used in accordance with accepted trademark practice, including identification of trademark owner's name. The Quantum Hardware, Software and Firmware are covered by U.S. Patent No. 4,914,431; 5,184,048; 5,267,318; 5,394,068; 5,448,142; 5,633,985; 5,832,431; 5,896,017; 5,940,005; and US and Foreign patents pending.

No Other Rights

QSI Industries, Inc. retains ownership of the Quantum Hardware design and operating Software/Firmware code. Except as stated above, this agreement does not grant you any rights to intellectual property rights to the Quantum Software, Firmware or Hardware. The use of any trademarks as herein authorized does not give you any rights of ownership in that trademark.

© 2006 All rights reserved. Printed in China. Information in this publication supersedes that in all previous published material. The contents and the product it describes are subject to change without notice. QSI is a registered trademark of QSI Industries, Inc. Quantum, Quantum System, Sound-of-Power, Scale Sound, Regulated Throttle Control, QARC, are trademarks of QSI Industries, Inc. MRC is a trademark of Model Rectifier Corporation. All other trademarks are the property of their respective holders. QSI makes no representations or warranties with respect to this publication. In no event shall QSI Industries, Inc., be liable for any damages, direct or incidental, arising out of or related to the use of this publication.
Universal Q1R Steam manual P F(17) G(3) J(2).doc 4/06

**QSI Industries, Inc.
Beaverton, OR**

71 Quantum Analog Remote Control (QARC) Technology
72 Not all Quantum equipped locomotives contain QARC Technology.